

Braden Keiser

Complex simulation protocol for 7M1Z complexed with HMG-CoA and NADPH

2024/02/06

### Software prerequisites:

Avogadro: [Download Avogadro \(sourceforge.net\)](https://sourceforge.net/projects/avogadro/)

Rstudio and R: [RStudio Desktop - Posit](https://posit.co/download/rstudio-desktop/)

Kate: [Kate - Microsoft Apps](https://aka.ms/kate-windows)

Pdb-tools (command-line, conda, **your computer and HPC**): [pdb-tools | A swiss army knife for editing PDB files. \(bonvinlab.org\)](https://github.com/bonvinlab/pdb-tools)

in conda: `conda install pdb-tools`

if conda doesn't work: `pip install pdb-tools`

Miniconda (your computer and HPC): below

VMD

### Notes:

*THIS PROTOCOL WAS INITIALLY DESIGNED TO RUN ON A TARA SUBMISSION SERVER AND WAS TAILORED TO A SPECIFIC HPC ENVIRONMENT. THE FOLLOWING METHOD IS FOR REFERENCE AND WILL LIKELY NEED SUBMISSION/DEPENDENCY MAINTENANCE WITHIN THE NESTED DIRECTORIES FOR RELEVANCE.*

HOME = a placeholder name to censor identification content in the original protocol

*Text in Courier is emulation of code that can be run within a console terminal*

You can begin by running next\_protein.sh (step 1) with the WT-complex\_protonated.pdb and generating a 200ns simulation for the WT complex. It doesn't matter if your starting structure has ligand in it; the input parameterization step will remove everything and add in my pre-parameterized ligands. Moreover, **the WT-complex\_protonated.pdb is already appropriately protonated, so step 0 is not needed.**

The only other issue I can see is getting RMSD, RMSF, and RoG. These require the use of R (bio3d) or python (MDAnalysis) to analyze the data locally. This can be done on the HPC, but it requires setting up your conda environment. Instructions for setting up miniconda on linux are here: [How to Install Miniconda on Ubuntu 20.04 - VarHowto](https://varhowto.com/linux/ubuntu/20.04/how-to-install-miniconda/). Perform these steps in your own directory (i.e.,

```
cd ~/.
```

Then, begin the HowTo.

We can setup MDAnalysis in conda environment:

```
conda create -n mdsim
```

```
conda install -c conda-forge MDAnalysis
```

Setting up R in conda on the HOME HPC is much more difficult. We will use R on your local computer following the PBSA to generate some simple graphs of the PBSA data. You can also use excel for displaying some of the files (as mentioned in later section).

## 0. Structure Preparation

Ligand files have already been prepared on the HOME HPC in the HMG directory. All that needs to be done is that the mutated variant file be generated and protonated. Care must be taken to make sure the coordinates of the mutated PDB file match those with the WT PDB file obtained in the HMG directory. During input processing, the ligand coordinates will be deposited into the new structure based on their crystal structure geometries.

Not much is needed to do before beginning the Amber work; however, two important processes must be performed: protonation with PDB2PQR and manual protonation of the His741 (H381 in chain B). The HOME HPC HMG directory has a **new pt0\_protonation.sh** that will protonate the structure at pH 6.5, but this does not protonate His741 like the Haines paper recommended for ideal active site interactions.

Thus, the **overview of this section**:


- I. `bash pt0_protonation.sh [your_mutant].pdb`
- II. protonate the histidine at ~381 or ~741 (depending on pdb numbering)
- III. align new mutant to WT to make sure they are aligned

Once you have your mutant file, you can align it to the WT complex (WT-complex\_protonated.pdb) in pymol with:

```
align [new_mutant], WT-complex_protonated
```

When both of them are open in the same window. After that, save the new protein and open it alone. Within chain B's ~381 region or at 740/741 in a renumbered format, there should be a '**QKGHMA**' motif, and once selected, these will be revealed to be in the active site.

Select '**GHM**' of the motif and on the right-hand side of pymol, press A → copy-to-object → new. Now, click the main protein so it becomes hidden (grey to black nameplate) and only the new object is shown as a small alpha helix curve. We can save this as a PDB 'h741.pdb' and open it in Avogadro.



Now, we save this PDB and open both this and the protonated mutant PDB with **Kate**.

Copy all atoms from **only** the HIS residue in the H741.pdb and copy it to the proper location in the mutant profile which will be around residue 740/741 if the residues have renumbered from 1, or it will be around 381 if each chain is respectively numbered in your PDB file. Copy over **all atoms of HIS in the mutant**. The motif will be three-letter AA code now: **GLN-LYS-GLY-HIS-MET-ALA**.

392	ATOM	11389	HA2	GLY	739	33.165	50.378	42.783	1.00	0.00	H
393	ATOM	11390	HA3	GLY	739	34.676	49.746	43.590	1.00	0.00	H
394	ATOM	11391	C	GLY	739	34.938	51.663	42.758	1.00	0.00	C
395	ATOM	11392	O	GLY	739	34.269	52.694	42.938	1.00	0.00	O
396	ATOM	8	N	HIP	740	36.285	51.673	42.439	1.00	0.00	N
397	ATOM	9	CA	HIP	740	37.002	52.897	42.220	1.00	0.00	C
398	ATOM	10	C	HIP	740	36.352	53.868	41.248	1.00	0.00	C
399	ATOM	11	O	HIP	740	36.230	55.046	41.593	1.00	0.00	O
400	ATOM	12	CB	HIP	740	38.490	52.581	41.949	1.00	0.00	C
401	ATOM	13	CG	HIP	740	39.459	53.724	42.048	1.00	0.00	C
402	ATOM	14	CD2	HIP	740	39.335	54.943	42.608	1.00	0.00	C
403	ATOM	15	ND1	HIP	740	40.624	53.617	41.375	1.00	0.00	N1+
404	ATOM	16	CE1	HIP	740	41.215	54.809	41.435	1.00	0.00	C
405	ATOM	17	NE2	HIP	740	40.448	55.644	42.240	1.00	0.00	N
406	ATOM	18	H	HIP	740	36.829	50.825	42.369	1.00	0.00	H
407	ATOM	19	HA	HIP	740	37.022	53.482	43.139	1.00	0.00	H
408	ATOM	20	HB2	HIP	740	38.890	51.794	42.588	1.00	0.00	H
409	ATOM	21	HB3	HIP	740	38.610	52.126	40.965	1.00	0.00	H
410	ATOM	22	HD1	HIP	740	40.810	52.814	40.791	1.00	0.00	H
411	ATOM	23	HD2	HIP	740	38.455	55.360	43.076	1.00	0.00	H
412	ATOM	24	HE1	HIP	740	42.137	55.111	40.961	1.00	0.00	H

Don't worry about residue name or number errors, here. We will first automatically renumber. In **conda**, navigate to the folder with the protein name stored and run **pdb\_reres**:

```
pdb_reres -1 [mutant_protein_protonated].pdb > [mutant_protein_protonated]_renum.pdb
```

Now, your whole molecule should be renumbered from 1 to ~784. Copy this to:

```
cp [mutant_protein_protonated]_renum.pdb [mutant_protein]_protonated.pdb
```

Of course, you will want to open this in pymol and check the area, making sure everything is correct.

Upload this to the HOME HPC in the main folder of the HMG directory. We can now begin.

## 1. Folder setup

After logging into the HOME HPC, edit your **.bashrc** by typing:

```
nano ~/.bashrc
```

add the line to the bottom:

```
export hmg=/path/to/your/hmg
```

ctrl+x then press y and enter.

Now, we can directly access the hmg directory by typing:

```
cd $hmg
```

Upload your finished pdb to this folder and use the **next\_protein.sh** script to setup your folder:

```
bash next_protein.sh [mutant]_protonated.pdb [folder_name]
```

```
cd [folder_name]
```

```
e.g.,
```

```
bash next_protein.sh WT-complex_protonated.pdb WT
```

```
cd WT
```

## 2. Input parameterization

Perform input parameterization by running the pt1 script **WITHOUT 'PDB'**:

```
bash pt1_input-parameterization_2024.sh [mutant]_protonated y
bash pt1_input-parameterization_2024.sh WT-complex_protonated y
```

### 3. Minimization

Run minimization via:

```
sbatch run_pt2_water-min.slurm
```

### 4. Heat and water equilibration

Run equilibration via:

(input mutant name is one you give to yourself – it won't be searching for a file name, but will name subsequent files with the prefix)

```
sbatch run_pt3-NVT_EQ.slurm [mutant] [test_num] [temp] [mpi]
```

e.g., `sbatch run_pt3-NVT_EQ.slurm WT 1 300 32`

### 5. Production

Production is initiated with:

```
sbatch run_pt4_production.slurm [folder_name] [test_num]
```

e.g.,

```
sbatch run_pt4_production.slurm tested_wt 1
```

```
sbatch run_pt4_production.slurm WT-test 2
```

(These are the parent folders we created with next\_protein.sh and are in the HMG directory)

### 6. Get analysis:

To get ligand information, **first we need to run the get\_results.sh** script to create our results directory and perform some stripping of water and ions and renumbering residues for good analysis.

```
bash get_results.sh [test_num] [mutant]
```

To get **RMSD of ligand**, you can run the ligand\_analysis.sh script following the completed of the production run and the running of get\_results.sh:

```
bash ligand_analysis.sh [test_num] [mutant]
```

A location will be the output here:

```
/path/to/your/...../XXXXXX.tar.gz
```

Copy this and you can use SCP to download it directly to your local machine in another tab of MobaXTerm:

e.g.,

scp [bkeiser@tara.nstda.or.th:/tarafs/...../XXXXX.tar.gz](mailto:bkeiser@tara.nstda.or.th:/tarafs/...../XXXXX.tar.gz) ./

tar xfvz XXXXX.tar.gz


and then your ligand information will be available.

You can get the graphical information of the rmsd information by running the Rscript for ligand analysis (hmg\_ligandanalysis.R) or you can view it in **Excel**, but first we need to extract only the relevant information into a new file using awk in **MobaXTerm**:

```
awk '{print $2}' hmg_rmsd.xvg > hmg_rmsd.csv
```

You will now have just a 1-column file. As Amber doesn't output comma-separated files, this is the easiest approach. The other column in the RMSD file is just for frames 1-[total\_num\_frames]. This is equivalent to the number of cells in Excel.

We can also **view the trajectory with VMD** by loading the tpr-protein.pdb and trj-small.xtc:



After reviewing the PBSA, we can make a distinction of where we want our 5ns to be for the PBSA calculation. Ideally, this should be the last 5ns of the simulation. But, this is not always doable if a mutation appears to disrupt ligand binding; therefore, the last 5ns of most stable RMSD can be used.

## 7. PBSA analysis

PBSA analysis is first prepped by:

```
bash prep_pt5_pbsa.sh [test_num] [mutant] [pbsa_start_frame] [pbsa_end_frame]
```

e.g.,

```
bash prep_pt5_pbsa.sh 1 WT 1500 2000
```

This will perform PBSA from 15ns-20ns. Often, we can extract every other frame, so only 250 frames are used here. This can be negated by removing “offset 2” in `hmg/qm_protocol/cpptraj_inputs/extract.in`

Following this, a new folder will appear in your mutant main folder: `pbsa_t[test_number]`. This is where the PBSA data will be stored.

In the main folder still, run the PBSA:

```
sbatch run_pt5_pbsa.sh [test_num] [mutant] [ligand_name]
```

e.g.,

```
sbatch run_pt5_pbsa.sh 1 WT HMG
```